



Original	Replacement	Original	Replacement
	Power		Power
	TV		9
	Text		9
	Source 2		<< / Tune-
	Source 1		>> / Tune+
	1		<=>
	2		0
	3		Shift + CH- /
	Contrast-		Shift + CH+ /
	Contrast+		Guide / EPG / -/--
	4		Left
	5		Right
	6		Vol-
	Brightness-		Vol+
	Brightness+		CH- / Page-
	7		CH+ / Page+
	8		Sound / Title
			Audio / Lang I/II
			Zoom / Size
			Mute / Dimmer



