



Original		Replacement	
	Power		Power
	Auto Setup		Auto
	Computer 1		Comp / Video
	Computer 2		Shift + Mode
	HDMI		3D / Invert
	Video		Shift + Comp / Video
	S-Video		Mode
	Up		Up
	Left		Left
	Enter		Enter
	Right		Right
	Down		Down
	Menu		Menu
	Default		Shift + Power
	Function		Source
	Return		Shift + Menu
	Freeze		Freeze / Timer

Original		Replacement	
	ID Set		Shift + Down
	ID All		Shift + Up
	Mute		Blank / Mute
	D.Zoom+/1		+ / Play
	Vol+/2		Vol + / Page +
	P-Timer/3		Volt / Focus
	AV Mute		Shift + Blank / Mute
	D.Zoom-/4		- / Stop
	Vol-/5		Vol - / Page -
	Keystone/6		Help / Info
	P IN P		Eco / Aspect

