



































































Original	Replacement	Original	Replacement
	Power		Power
	Optical		1
	Optical		Red / Netflix / Search
	Mute		Mute / Dimmer
	AUX		7
	AUX		Green / APP / Repeat
	BT		9
	BT		Yellow / YouTube / Repeat
	HDMI ARC		0
	HDMI ARC		Blue / Prime Video / Random
	Vol+		Vol+
	Vol+		Up
	I<		I<< / Preset-
	I<		Left
	Play/Pause / Pair		OK
	Play/Pause / Pair		Play / Slow
	Play/Pause / Pair		Pause / Step / Freeze
	>I		>>I / Preset+
	>I		Right
	Vol-		Vol-
	Vol-		Down
	News		Audio / Lang I/II
	Movie		Picture / Format
	Music		Sound / Title





Original	Replacement	Original	Replacement
Power	 Power		
Bluetooth	 9		
Source	 AV / Input / RDS		
Vol+	 Vol+		
Vol-	 Vol-		
Mute	 Mute / Dimmer		
>>I	 >>I / Preset+		
I<<	 I<< / Preset-		
Play/Pause	 Play / Slow		
Play/Pause	 Pause / Step / Freeze		
Bass+	 Right		
Bass-	 Left		
EQ	 Subtitle / EQ		
Tre+	 Up		
Tre-	 Down		

Original	Replacement

