



Original	Replacement
	Power
	Input
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Lang
	0
	TXT
	Vol+
	Mute
	P+

Original	Replacement
	Vol-
	Home
	P-
	Guide
	Up
	i
	Left
	OK
	Right
	Back
	Down
	Exit
	<<
	Pause
	>>
	Rec
	Play



