



Original	Replacement
Mute	Mute / Dimmer
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Menu	Menu / Home
0	0
Exit	Exit / Cancel / Clear
Up	Up
CH+	CH+ / Page+
Left	Left

Original	Replacement
Vol-	Vol-
OK	OK
Right	Right
Vol+	Vol+
Down	Down
CH-	CH- / Page-
Red	Red / Netflix / Search
EPG	Guide / EPG / -/-
Green	Green / APP / Repeat
Audio	Audio / Lang I/II
Yellow	Yellow / YouTube / Repeat
Subtitle	Subtitle / EQ
Blue	Blue / Prime Video / Random
TTX	Text / Goto
i	Info / Angle
FAV	Fav / Marker / PC
Tv/Radio	TV/Radio /



