















































Original		Replacement		Original		Replacement	
	Display		Display / Media		6		6
	Power		Power		7		7
	DVD/CD		Shift + 2		8		8
	DVD/CD		Shift + 3		9		9
	Tuner Band		Shift + 6		PGM		TV/Radio /
	SAT		Shift + 0		0		0
	Input Mode /		Blue / Prime Video / Random		+10 / Clear		Guide / EPG / -/--
	Input Mode /		AV / Input / RDS		+10 / Clear		Exit / Cancel / Clear
	VCR		Shift + 4		Volume+		Vol+
	Cable		Shift + 5		Audio / Set		Audio / Lang I/II
	TV		Shift + 1		CH+ / Repeat		Green / APP / Repeat
	Aux Front		Shift + 7		CH+ / Repeat		CH+ / Page+
	1		1		Volume-		Vol-
	2		2		Mute		Mute / Dimmer
	3		3		CH- / A.B		Yellow / YouTube / Repeat
	4		4		CH- / A.B		CH- / Page-
	5		5		Up		Up





Original		Replacement		Original		Replacement	
	Left		Left		Rear		Picture / Format
	Enter		OK		Listen Mode		Setup / OPT /
	Right		Right		Sound		Sound / Title
	Down		Down		SW		Text / Goto
	Return		Back / Return		Menu / PTY		Menu / Home
	On Screen /		Smart / List		Top Menu / PBC		D.Menu / Top
	I<< / P.Call-		I<< / Preset-				
	Play		Play / Slow				
	>>I / P.Call+		>>I / Preset+				
	S.Title / Rec		Subtitle / EQ				
	Stop / Auto/Mono		Stop / Hold				
	Pause / Preset		Pause / Step / Freeze				
	<< / Tune- / TV Vol.-		<< / Tune-				
	>> / Tune+ / TV Vol.+		>> / Tune+				
	Slow		Shift + Play /				
	Step		Shift + Pause / Step /				
	Center		Zoom / Size				

