



Original	Replacement
Power Receiver	Power
DVD	Shift + 2
TV	Shift + 1
DVD Recorder	Shift + 5
VCR	Shift + 4
Tuner / Band	Shift + 6
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Volume+	Vol+
Disc / Direct Tuning	Display / Media

Original	Replacement
0	0
$\geq 10 / -/-$	Guide / EPG / -/-
Volume-	Vol-
I<< / <<	I<< / Preset-
>> / >>I	>>I / Preset+
Up	Up
Left	Left
Enter	OK
Right	Right
Menu / Play List	Menu / Home
Down	Down
Muting	Mute / Dimmer
Subwoofer	Eject / Surround
Test	Text / Goto
Level	Smart / List
Effect	Info / Angle
-/L	CH- / Page-





	Original	Replacement		Original	Replacement
	+/R	 CH+ / Page+			
	OFF	 LANG I/II AUDIO			
	Dolby PL II	 TITLE SOUND			
	SFC	 EQ SUBTITLE			

