







Original	Replacement
	Muting
	Power
	Timer
	Clock Call
	Sleep
	TUNER
	CD
	iPod
	Line
	Bluetooth
	Stop
	Play / Pause
	<< / Tuning-
	I<< / Preset-
	>>I / Preset+
	>> / Tuning+
	Volume-

Original	Replacement
	Mute / Dimmer
	Power
	Shift + Sleep / Timer
	Setup / OPT /
	Sleep / Timer
	6
	3
	1
	2
	9
	Stop / Hold
	Play / Slow
	<< / Tune-
	I<< / Preset-
	>>I / Preset+
	>> / Tune+
	Vol-

Original	Replacement
	Volume+
	Menu
	Up
	Preset Memory
	Treble
	Left
	Enter
	Right
	Bass
	Mode
	Down
	Clear
	S.Bass
	Dimmer
	Shuffle
	Repeat
	Playlist+

Original	Replacement
	Vol+
	Menu / Home
	Up
	Smart / List
	Sound / Title
	Left
	OK
	Right
	Audio / Lang I/II
	Info / Angle
	Down
	Exit / Cancel / Clear
	Subtitle / EQ
	Shift + Mute / Dimmer
	Blue / Prime Video / Random
	Green / APP / Repeat
	CH+ / Page+



