













































































Original	Replacement
	 Power
	 Picture / Format
	 TV/Radio /
	 AV / Input / RDS
	 Shift + Red / Netflix /
	 D.Menu / Top
	 Shift + Blue / Prime
	 Shift + Yellow / YouTube /
	 Shift + Green / APP /
	 Sleep / Timer
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 Menu / Home
	 Shift + Menu /
	 Guide / EPG / -/-

Original	Replacement
	 Info / Angle
	 Exit / Cancel / Clear
	 Up
	 Left
	 OK
	 Right
	 Setup / OPT /
	 Down
	 Back / Return
	 Smart / List
	 Display / Media
	 Zoom / Size
	 << / Tune-
	 Play / Slow
	 >> / Tune+
	 Stop / Hold
	 Pause / Step / Freeze





Original		Replacement		Original		Replacement	
	REC		Rec / Rec Mode		?/eHELP		Eject / Surround
	Vol+		Vol+		0		0
	Mute		Mute / Dimmer		Last View		Fav / Marker / PC
	CH+		CH+ / Page+				
	Vol-		Vol-				
	Text		Text / Goto				
	CH-		CH- / Page-				
	STTL		Subtitle / EQ				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				

