





















































































































Original	Replacement	Original	Replacement
 Standby	 Power	 Tv Menu	 Menu / Home
 Source	 AV / Input / RDS	 DVD Menu	 D.Menu / Top
 Eject	 Eject / Surround	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 Enter	 OK
 3	 3	 Play	 Play / Slow
 4	 4	 Right	 Right
 5	 5	 Vol+	 Vol+
 6	 6	 Down	 Down
 7	 7	 PR+	 CH+ / Page+
 8	 8	 Vol-	 Vol-
 9	 9	 PR-	 CH- / Page-
 [■]/Wide	 Zoom / Size	 Red	 Red / Netflix / Search
 0	 0	 << / Tune-	 << / Tune-
 Recall	 Back / Return	 >> / Tune+	 >> / Tune+
 Picture	 Picture / Format	 Green	 Green / APP / Repeat
 Setup	 Setup / OPT /	 Yellow	 Yellow / YouTube / Repeat

Original	Replacement	Original	Replacement
 Standby	 Power	 Tv Menu	 Menu / Home
 Source	 AV / Input / RDS	 DVD Menu	 D.Menu / Top
 Eject	 Eject / Surround	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 Enter	 OK
 3	 3	 Play	 Play / Slow
 4	 4	 Right	 Right
 5	 5	 Vol+	 Vol+
 6	 6	 Down	 Down
 7	 7	 PR+	 CH+ / Page+
 8	 8	 Vol-	 Vol-
 9	 9	 PR-	 CH- / Page-
 [■]/Wide	 Zoom / Size	 Red	 Red / Netflix / Search
 0	 0	 << / Tune-	 << / Tune-
 Recall	 Back / Return	 >> / Tune+	 >> / Tune+
 Picture	 Picture / Format	 Green	 Green / APP / Repeat
 Setup	 Setup / OPT /	 Yellow	 Yellow / YouTube / Repeat



