































































































Original	Replacement	Original	Replacement
	Power		Power
	[=]		Text / Goto
	Enter		OK
	Vol+		Vol+
	Prog+		CH+ / Page+
	Vol-		Vol-
	Prog-		CH- / Page-
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	-/--		Guide / EPG / -/--
	0		0
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Repeat		Shift + Green / APP / Repeat





Original	Replacement
 Open/Close	 Eject / Surround
 Display	 Display / Media
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Wide Mode	 Zoom / Size
 Tv/Video	 TV/Radio /
 -/--/Search Mode	 Guide / EPG / -/--
 0	 0
 Clear	 Exit / Cancel / Clear

Original	Replacement
 Time	 Sleep / Timer
 Red/Shuffle	 Red / Netflix / Search
 Green/Program	 Green / APP / Repeat
 Repeat	 Shift + Green / APP /
 A-B	 Shift + Yellow / YouTube /
 Yellow/Audio	 Yellow / YouTube / Repeat
 Blue/Angle	 Blue / Prime Video / Random
 [=]/Subtitle	 Text / Goto
 Subtitle On/Off	 Subtitle / EQ
 AV Center	 AV / Input / RDS
 < I Step	 Shift + Left
 Step II>	 Shift + Right
 <I Slow	 CH- / Page-
 Slow II>	 CH+ / Page+
 AV Vol+	 Vol+
 I<</Prev	 I<< / Preset-
 >>I/Next	 >>I / Preset+





Original	Replacement
 << Scan	 << / Tune-
 >> Scan	 >> / Tune+
 AV Vol-	 Vol-
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 Set Up	 Setup / OPT /
 Title	 Sound / Title
 DVD Menu	 D.Menu / Top
 Return	 Back / Return
 Tv/DVD	 +  Shift + TV/Radio / Program
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Down	 Down

Original	Replacement

