






































































| Original | Replacement | Original | Replacement |
|---|-------------|---|-----------------------------|
|  | Power |  | Power |
|  | Mute |  | Mute / Dimmer |
|  | TV/RAD |  | TV/Radio / |
|  | www |  | Sleep / Timer |
|  | PIP |  | Zoom / Size |
|  | Grid |  | D.Menu / Top |
|  | Swap |  | Back / Return |
|  | Sub ch |  | Setup / OPT / |
|  | P/Pg+ |  | CH+ / Page+ |
|  | RCL |  | Display / Media |
|  | Vol+ |  | Vol+ |
|  | P/Pg- |  | CH- / Page- |
|  | i |  | Info / Angle |
|  | Vol- |  | Vol- |
|  | FAV |  | Fav / Marker / PC |
|  | Check |  | Smart / List |
|  | Message |  | Eject / Surround |
|  | EPG |  | Guide / EPG / -/-- |
|  | Up |  | Up |
|  | Menu |  | Menu / Home |
|  | Left |  | Left |
|  | OK |  | OK |
|  | right |  | Right |
|  | Exit |  | Exit / Cancel / Clear |
|  | Down |  | Down |
|  | Red |  | Red / Netflix / Search |
|  | Green |  | Green / APP / Repeat |
|  | Yellow |  | Yellow / YouTube / Repeat |
|  | Blue |  | Blue / Prime Video / Random |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |





| Original | | Replacement | | Original | | Replacement | |
|---|--------|---|-----------------------|---|-------|---|-------------------|
|  | 6 |  | 6 |  | TXT |  | Text / Goto |
|  | 7 |  | 7 |  | Audio |  | Audio / Lang I/II |
|  | 8 |  | 8 | | | | |
|  | 9 |  | 9 | | | | |
|  | Music |  | Sound / Title | | | | |
|  | 0 |  | 0 | | | | |
|  | Photo |  | Picture / Format | | | | |
|  | Rec |  | Rec / Rec Mode | | | | |
|  | << |  | << / Tune- | | | | |
|  | Play |  | Play / Slow | | | | |
|  | >> |  | >> / Tune+ | | | | |
|  | Recall |  | AV / Input / RDS | | | | |
|  | > |  | >> / Preset+ | | | | |
|  | Stop/→ |  | Stop / Hold | | | | |
|  | Pause |  | Pause / Step / Freeze | | | | |
|  | []]]] |  | Shift + Zoom / | | | | |
|  | [...] |  | Subtitle / EQ | | | | |

