







































































Original	Replacement	Original	Replacement
 Standby	 Power	 Red/Sound	 Red
 1	 1	 Green/Picture	 Green
 2	 2	 Yellow/VGA	 Yellow
 3	 3	 Blue/TV	 Blue
 4	 4	 [=+]/Hold	 Options
 5	 5	 [=?]/Reveal	 TV/R
 6	 6	 [=◇]/Size	 Format
 7	 7	 [/ =]	 Smart
 8	 8	 [=i]/Index	 Shift + Info
 9	 9	 [O]/Subpage	 Media
 0	 0	 [=]/Text	 Text
 P.P	 Back	 Vol+	 Vol +
 FAV	 Pre Ch	 Vol-	 Vol -
 DTV EPG FAV	 Guide	 CH+	 Ch +
 DTV EPG FAV	 AV	 CH-	 Ch -
 Mute	 Mute	 PIP	 3D
 Audio	 Dual	 Wide	 Eject



