













































Original	Replacement	Original	Replacement
	Power		Power
			Eject
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Shift + Guide
	Recall		Back
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	P.Mode		Shift + Format
	S.Mode		Shift + Dual
	Mute		Mute
	TXT		Text
	Aspect		Format
	Audio		Shift + 3D
	Display		Info
	Sleep		Sleep
	Up / PR +		Up
	Up / PR +		Ch +
	Down / PR -		Down
	Down / PR -		Ch -
	Right / Vol +		Right
	Right / Vol +		Vol +
	Left / Vol -		Left
	Left / Vol -		Vol -





Original		Replacement		Original	Replacement
	Enter		Ok		
	Source		AV		
	Menu		Menu		
	Hold		Stop		
	Mix		Shift + Text		
	Subpage		Shift + Subt		
	Size		Shift + Eject		
	Index		3D		
	Reveal		Media		
	DTV/Radio		TV/R		
	List		List		
	EPG		Guide		
	FAV		Pre Ch		
	Page Down		I<<		
	Page Up		>>I		
	Still		Pause		
	Subtitle		Subt		

