






















































































Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 DTV/ATV	 Smart
 Return	 Back
 P.Mode	 Shift + Format
 S.Mode	 Shift + Dual
 Sleep	 Sleep

Original	Replacement
 Menu	 Menu
 Exit	 Exit
 Source	 AV
 Display	 Info
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Lang/Audio	 Dual
 Reclist	 List
 Rec	 Rec
 FAV/List	 Pre Ch
 Freeze	 Media
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +





Original		Replacement		Original		Replacement	
	CH-		Ch -		Green		Green
	EPG		Guide		Yellow		Yellow
	Aspect		3D		Blue		Blue
	<<		<<				
	>>		>>				
	Pause/Timeshift		Pause				
	I<</Cancel		I<<				
	>>I/Sub.Pg		>>I				
	Stop/Index		Stop				
	Play		Play				
	Tv/Radio		TV/R				
	Subtitle		Subt				
	Reveal		Options				
	Size		Format				
	Hold		Eject				
	Text		Text				
	Red		Red				

