



Original	Replacement
Power	Power
Source	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Preview	Guide
CH RTN	Pre Ch
Picture	Format
Brightness	Info
Up / CH +	Up

Original	Replacement
Up / CH +	Ch +
Down / CH -	Down
Down / CH -	Ch -
Right / Vol +	Right
Right / Vol +	Vol +
Left / Vol -	Left
Left / Vol -	Vol -
Menu	Menu
Menu	Ok
Mute	Mute
Sleep	Sleep
PIP	Play
PIP CH	Pause
PIP POS	Stop
Teletext	Text
Red	Red
Green	Green



