











































































































































Original		Replacement		Original		Replacement	
	Power		Power		4		4
	OK		Ok		5		5
	Up		Up		6		6
	Down		Down		7		7
	Right		Right		8		8
	Left		Left		9		9
	Menu		Menu		0		0
	Mute		Mute		P<P		Pre Ch
	> <		Smart		[i+]		Info
	[≡]		Text		[112]		Options
	P+		Ch +		[-O-]/Active Control		Media
	P-		Ch -		[<>]		Format
	Vol+		Vol +		Source		AV
	Vol-		Vol -		(O)		TV/R
	1		1		Red		Red
	2		2		Green/Timer		Green
	3		3		Yellow/[]		Yellow









































































Original	Replacement	Original	Replacement
 Blue/[...]	 Blue	 P- AMP	 Shift + Ch -
 Rec	 Rec	 Mute AMP	 Shift + Mute
 <<	 <<	 Vol+ AMP	 Shift + Vol +
 Stop	 Stop	 Vol- AMP	 Shift + Vol -
 Play	 Play	 1 AMP	 Shift + 1
 >>	 >>	 2 AMP	 Shift + 2
 [[]]	 Guide	 3 AMP	 Shift + 3
 Power AMP	 Shift + Power	 4 AMP	 Shift + 4
 [] AMP	 Shift + Text	 5 AMP	 Shift + 5
 [[]] AMP	 Shift + Guide	 6 AMP	 Shift + 6
 OK AMP	 Shift + Ok	 7 AMP	 Shift + 7
 Up AMP	 Shift + Up	 8 AMP	 Shift + 8
 Down AMP	 Shift + Down	 9 AMP	 Shift + 9
 Right AMP	 Shift + Right	 0 AMP	 Shift + 0
 Left AMP	 Shift + Left	 P<P AMP	 Shift + Pre Ch
 Menu AMP	 Shift + Menu	 >> AMP	 Shift + >>
 P+ AMP	 Shift + Ch +	 << AMP	 Shift + <<





Original		Replacement		Original		Replacement	
	Power		Power		P-		Ch -
	Source		AV		Vol+		Vol +
	>>		>>		Vol-		Vol -
	<<		<<		1		1
	Stop		Stop		2		2
	Play		Play		3		3
	[[[]]]		Guide		4		4
	[[=]]		Text		5		5
	OK		Ok		6		6
	Up		Up		7		7
	Down		Down		8		8
	Right		Right		9		9
	Left		Left		0		0
	> <		Smart		[i+]		Info
	Menu		Menu		P<P		Pre Ch
	Mute		Mute		[1 2]		Options
	P+		Ch +		[-O-]/Active Control		Media









































































Original	Replacement	Original	Replacement
	[<>]		Format




































Original		Replacement		Original		Replacement	
	Power		Power		Mute		Mute
	Source		AV		P+		Ch +
	(O		TV/R		P-		Ch -
	Red		Red		Vol+		Vol +
	Green/Timer		Green		Vol-		Vol -
	Yellow/[]		Yellow		> <		Smart
	Blue/[...]		Blue		Menu		Menu
	>>		>>		1		1
	Rec		Rec		2		2
	<<		<<		3		3
	Stop		Stop		4		4
	Play		Play		5		5
	OK		Ok		6		6
	Up		Up		7		7
	Down		Down		8		8
	Right		Right		9		9
	Left		Left		0		0





























































Original	Replacement	Original	Replacement
	[i+] Info		> < VCR
	P<P Pre Ch		Menu VCR
	[1 2] Options		P+ VCR
	[-O-]/Active Control		P- VCR
	[<>] Format		1 VCR
	Power VCR		2 VCR
	Source VCR		3 VCR
	Rec VCR		4 VCR
	>> VCR		5 VCR
	<< VCR		6 VCR
	Stop VCR		7 VCR
	Play VCR		8 VCR
	OK VCR		9 VCR
	Up VCR		0 VCR
	Down VCR		[i+] VCR
	Right VCR		P<P VCR
	Left VCR		





Original		Replacement		Original		Replacement	
	Power		Power		2		2
	>>		>>		3		3
	<<		<<		4		4
	Stop		Stop		5		5
	Play		Play		6		6
	[[I]]		Guide		7		7
	Up		Up		8		8
	Down		Down		9		9
	Right		Right		0		0
	Left		Left		[i+]		Info
	>I<		Smart		P<P		Pre Ch
	Mute		Mute				
	Vol+		Vol +				
	Vol-		Vol -				
	P+		Ch +				
	P-		Ch -				
	1		1				

