












































Original	Replacement
	
Power	Power
	
Input	AV / Input / RDS
	
Timer	Sleep / Timer
	
I-II	Audio / Lang I/II
	
X	Display / Media
	
Red	Red / Netflix / Search
	
Green	Green / APP / Repeat
	
Yellow	Yellow / YouTube / Repeat
	
Blue	Blue / Prime Video / Random
	
Smart Sound	Sound / Title
	
Smart Picture	Picture / Format
	
[1 2]	Smart / List
	
Menu	Menu / Home
	
Text	Text / Goto
	
Up	Up
	
Left	Left
	
Right	Right

Original	Replacement
	
Down	Down
	
Vol+	Vol+
	
Vol-	Vol-
	
P+	CH+ / Page+
	
P-	CH- / Page-
	
Mute	Mute / Dimmer
	
1	1
	
2	2
	
3	3
	
4	4
	
5	5
	
6	6
	
7	7
	
8	8
	
9	9
	
0	0
	
[i+]	Info / Angle



