


















































































Original		Replacement		Original		Replacement	
	Power		Power		Internet/PIP		Media
	HDMI/Control		Smart		1		1
	Rec		Rec		2		2
	Stop		Stop		3		3
	Play		Play		4		4
	Pause		Pause		5		5
	<<		<<		6		6
	>>		>>		7		7
	1<<		1<<		8		8
	>>1		>>1		9		9
	Red/Zoom/↑ ↓		Red		0		0
	Green/Repeat/↓		Green		Text		Text
	Yellow/Root		Yellow		Info		Info
	Blue/Title		Blue		Source		AV
	Screen		Format		OK		Ok
	Lang		Dual		Up		Up
	Subtitle		Subt		Down		Down





Original	Replacement	Original	Replacement
 Right	 Right		
 Left	 Left		
 P+	 Ch +		
 P-	 Ch -		
 Vol+	 Vol +		
 Vol-	 Vol -		
 Menu	 Menu		
 Mute	 Mute		
 Return	 Back		
 Swap	 Pre Ch		
 FAV	 Shift + Pre Ch		
 EPG	 Guide		
 Sleep	 Sleep		
 Search Mode	 Shift + AV		
 Ball/Angle	 Options		
 Display	 Shift + Info		
 Presets	 TV/R		

Original	Replacement

