





































Original	Replacement	Original	Replacement
 MUTE	 Mute	 Green	 Green
 Power	 Power	 P:P	 Pre Ch
 1	 1	 Yellow	 Yellow
 2	 2	 Analog	 Smart
 3	 3	 Blue	 Blue
 4	 4	 Up	 Up
 5	 5	 P+	 Ch +
 6	 6	 P-	 Ch -
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Vol+	 Vol +
 0	 0	 Vol-	 Vol -
 -/--	 Guide	 Left	 Left
 AV	 AV	 Recall	 Back
 Menu	 Menu	 Sleep	 Sleep
 Red	 Red	 Status	 3D
 OK	 Ok	 Tv/TXT	 Text





Original		Replacement		Original	Replacement
	Stop		Stop		
	Reveal		Media		
	Size		Format		
	Mix		Options		
	Index		Info		
	Subcode		Subt		
	Cancel		Shift + Back		

