













































Original	Replacement
 Power	 Power
 Eject / Tv/Radio	 Eject
 Eject / Tv/Radio	 TV/R
 Red/Goto	 Red
 Green/Angle	 Green
 Yellow/Repeat	 Yellow
 Blue/A-B	 Blue
 FAV	 Pre Ch
 Text	 Text
 Freeze/Hold	 List
 Sleep	 D. Menu
 Subtitle	 Subt
 Zoom/Size	 Format
 Aspect	 3D
 Subpage	 Smart
 Media	 Media
 Play	 Play

Original	Replacement
 Pause	 Pause
 <<	 <<
 >>	 >>
 Rec / D.Setup	 Rec
 Rec / D.Setup	 Options
 Stop	 Stop
 I<<	 I<<
 >>I/Index	 >>I
 Menu	 Menu
 Title/Exit	 Dual
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Source	 Sleep
 EPG/D.Menu	 Exit





Original	Replacement
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Display	 Info
 CH+	 Ch +
 CH-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 GUIDE Guide

Original	Replacement
 Back	 Back
 Lang / Audio	 AV
 P.Mode	 Shift + Format
 S.Mode	 Shift + Dual





Original	Replacement
 Power	 Power
 Eject / TV/Radio	 Eject
 Eject / Tv/Radio	 TV/R
 Red/Goto	 Red
 Green/Angle	 Green
 Yellow/Repeat	 Yellow
 Blue/A-B	 Blue
 FAV	 Pre Ch
 Text	 Text
 Freeze/Hold	 List
 Sleep	 Sleep
 Subtitle	 Subt
 Zoom/Size	 Format
 Aspect	 3D
 Subpage	 Smart
 Media	 Media
 Play	 Play

Original	Replacement
 Pause	 Pause
 <<	 <<
 >>	 >>
 Rec	 Rec
 D.Setup	 Options
 Stop	 Stop
 I<<	 I<<
 >>I/Index	 >>I
 Menu	 Menu
 Title/Exit	 Exit
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Source	 AV
 D.Menu / EPG	 Shift + Guide





Original	Replacement
D.Menu / EPG	D. Menu
Vol+	Vol +
Vol-	Vol -
Mute	Mute
Display	Info
CH+	Ch +
CH-	Ch -
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0

Original	Replacement
-/--	Guide
Back	Back
Lang/Audio	Dual
P.Mode	Shift + Format
S.Mode	Shift + Dual

