



Original	Replacement	Original	Replacement
	Standby		Power
	Auto		Smart
	Tv/Radio		TV/R
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Shift + Guide
	Back		Back
	Vol+		Vol +
	Vol-		Vol -
	CH+		Ch +
	CH-		Ch -
	Nicam/A2		Options
	Aspect		3D
	Display		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Menu		Menu
	Exit		Exit
	Source		AV
	P.Mode		Shift + Format
	S.Mode		Shift + Dual
	Sleep		Sleep





Original	Replacement
	 Pre Ch
	 Shift + Ch -
	 Shift + Ch +
	 Shift + AV
	 Guide
	 Text
	 Dual
	 Subt
	 List
	 Eject
	 D. Menu
	 Media
	 Format
	 Play
	 Pause
	 <<
	 >>

Original	Replacement
	 Rec
	 Stop
	 I<<
	 >>I
	 Red
	 Green
	 Yellow
	 Blue

