



| Original | Replacement |
|--|---|
|  Power |  Power |
|  Mute |  Mute / Dimmer |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  TV / Radio |  TV/Radio / |
|  TV / Sat |  Display / Media |
|  Menu |  Menu / Home |
|  EPG |  Guide / EPG / -/- |
|  Info |  Info / Angle |

| Original | Replacement |
|--|---|
|  Exit |  Exit / Cancel / Clear |
|  Up / CH+ |  Up |
|  Up / CH+ |  CH+ / Page+ |
|  Down / CH- |  Down |
|  Down / CH- |  CH- / Page- |
|  OK |  OK |
|  Right / Vol+ |  Right |
|  Right / Vol+ |  Vol+ |
|  Left / Vol- |  Left |
|  Left / Vol- |  Vol- |
|  Group |  Smart / List |
|  Pause |  Pause / Step / Freeze |
|  Color |  Picture / Format |
|  Page+ |  Shift + CH+ / |
|  Page- |  Shift + CH- / |
|  Page+ |  >> / Preset+ |
|  Page- |  I<< / Preset- |





| Original | Replacement | Original | Replacement |
|---------------|-----------------------------|----------|-------------|
| UHF | AV / Input / RDS | | |
| Red / Recall | Red / Netflix / Search | | |
| Red / Recall | Back / Return | | |
| Green / Audio | Green / APP / Repeat | | |
| Green / Audio | Audio / Lang I/II | | |
| Yellow / Text | Yellow / YouTube / Repeat | | |
| Yellow / Text | Text / Goto | | |
| Blue | Blue / Prime Video / Random | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Replacement | Original | Replacement |
|----------|-------------|----------|-------------|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

