



































































| Original  |              | Replacement   |                             | Original  |           | Replacement   |                       |
|---|--------------|---|-----------------------------|---|-----------|---|-----------------------|
|    | Power        |    | Power                       |    | <<        |    | << / Tune-            |
|    | Tv/Radio     |    | TV/Radio /                  |    | >>        |    | >> / Tune+            |
|    | Red          |    | Red / Netflix / Search      |    | Rec       |    | Rec / Rec Mode        |
|    | Green        |    | Green / APP / Repeat        |    | Stop      |    | Stop / Hold           |
|    | Yellow       |    | Yellow / YouTube / Repeat   |    | I<<       |    | I<< / Preset-         |
|    | Blue         |    | Blue / Prime Video / Random |    | >>I/Index |    | >>I / Preset+         |
|    | P.Mode --    |    | Fav / Marker / PC           |    | Menu      |    | Menu / Home           |
|    | Text         |    | Text / Goto                 |    | Up        |    | Up                    |
|    | Hold         |    | Shift + Stop /              |    | Audio     |    | Audio / Lang I/II     |
|    | S.Mode --    |    | Guide / EPG / -/--          |    | Left      |    | Left                  |
|   | Subtitle     |   | Subtitle / EQ               |   | OK        |   | OK                    |
|  | Size         |  | Zoom / Size                 |  | Right     |  | Right                 |
|  | Aspect       |  | Shift + Picture / Format    |  | Sleep     |  | Sleep / Timer         |
|  | Subpage      |  | Eject / Surround            |  | Down      |  | Down                  |
|  | Media        |  | Smart / List                |  | Exit      |  | Exit / Cancel / Clear |
|  | Play / Pause |  | Play / Slow                 |  | Vol+      |  | Vol+                  |
|  | Play / Pause |  | Pause / Step / Freeze       |  | Mute      |  | Mute / Dimmer         |































































| Original                   | Replacement                   |
|----------------------------|-------------------------------|
| CH+ / Page+                | CH+ / Page+                   |
| Vol-                       | Vol-                          |
| Display                    | Display / Media               |
| CH- / Page-                | CH- / Page-                   |
| 1                          | 1                             |
| 2                          | 2                             |
| 3                          | 3                             |
| 4                          | 4                             |
| 5                          | 5                             |
| 6                          | 6                             |
| 7                          | 7                             |
| 8                          | 8                             |
| 9                          | 9                             |
| Shift + Guide / EPG / -/-- | +  Shift + Guide / EPG / -/-- |
| 0                          | 0                             |
| Recall                     | Back / Return                 |
| Source                     | AV / Input / RDS              |

| Original | Replacement      |
|----------|------------------|
| Smart TV | Picture / Format |
| Mouse    | Sound / Title    |













































| Original  | Replacement   | Original  | Replacement   |
|---|---|---|---|
|  Power     |  Power                       |  <<        |  << / Tune-              |
|  Tv/Radio  |  TV/Radio /                  |  >>        |  >> / Tune+              |
|  Red       |  Red / Netflix / Search      |  Rec       |  Rec / Rec Mode          |
|  Green     |  Green / APP / Repeat        |  Stop      |  Stop / Hold             |
|  Yellow    |  Yellow / YouTube / Repeat   |  I<<       |  I<< / Preset-           |
|  Blue      |  Blue / Prime Video / Random |  >>I/Index |  >>I / Preset+           |
|  P.Mode    |  Picture / Format            |  Menu      |  Menu / Home             |
|  Text      |  Text / Goto                 |  Up        |  Up                      |
|  Hold      |  Shift + Stop /              |  Audio     |  Audio / Lang I/II       |
|  S.Mode    |  Sound / Title               |  Left      |  Left                    |
|  Subtitle |  Subtitle / EQ              |  OK       |  OK                     |
|  Size    |  Zoom / Size               |  Right   |  Right                 |
|  Aspect  |  Shift + Picture / Format  |  Sleep   |  Sleep / Timer         |
|  Subpage |  Eject / Surround          |  Down    |  Down                  |
|  Media   |  Smart / List              |  Exit    |  Exit / Cancel / Clear |
|  Play    |  Play / Slow               |  Vol+    |  Vol+                  |
|  Pause   |  Pause / Step / Freeze     |  Mute    |  Mute / Dimmer         |





| Original   | Replacement  |
|--|--|
|  CH+      |  CH+ / Page+                  |
|  Vol-     |  Vol-                         |
|  Display  |  Display / Media              |
|  CH-      |  CH- / Page-                  |
|  1        |  1                            |
|  2        |  2                            |
|  3        |  3                            |
|  4        |  4                            |
|  5        |  5                            |
|  6       |  6                           |
|  7      |  7                          |
|  8      |  8                          |
|  9      |  9                          |
|  -/--   |  Shift + Guide / EPG / -/-- |
|  0      |  0                          |
|  Recall |  Back / Return              |
|  Source |  AV / Input / RDS           |

| Original   | Replacement  |
|--|--|
|  SMART TV |  Fav / Marker / PC  |
|  MOUSE    |  Guide / EPG / -/-- |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |

