







































































Original		Replacement		Original		Replacement	
	Power		Power		Smart		Smart / List
	1		1		P-		CH- / Page-
	2		2		Home		Shift + Home / Menu /
	3		3		Guide		Guide / EPG / -/-
	4		4		i		Info / Angle
	5		5		Up		Up
	6		6		Left		Left
	7		7		OK		OK
	8		8		Right		Right
	9		9		Down		Down
	Lang.		Audio / Lang I/II		←		Back / Return
	0		0		Exit		Exit / Cancel / Clear
	[ = ] . .		Subtitle / EQ		Netflix		Shift + Red / Netflix /
	Vol+		Vol+		YouTube		Shift + Yellow / YouTube /
	Mute		Mute / Dimmer		prime video		Shift + Blue / Prime
	P+		CH+ / Page+		Google Play		Picture / Format
	Vol-		Vol-		Menu		Menu / Home



