



| Original | Replacement |
|--|---|
|  Power |  Power |
|  [i]/Info |  Info |
|  Mute |  Mute |
|  I-II |  Dual |
|  OK/Select |  Ok |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  -/--/+10 |  +  Shift + Guide |
|  Exit |  Exit |

| Original | Replacement |
|--|---|
|  Menu |  Menu |
|  Red/↑/Return |  Red |
|  Green/↓/Subtitle |  Green |
|  Yellow/Audio |  Yellow |
|  Blue/Angle |  Blue |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  P+ |  Ch + |
|  P- |  Ch - |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  Play |  Play |
|  Pause |  Pause |
|  Stop |  Stop |
|  << |  << |









































































| Original | | Replacement | | Original | | Replacement | |
|---|---------------|---|----------------|----------|--|-------------|--|
|  | >> |  | >> | | | | |
|  | [TV] |  | TV/R | | | | |
|  | D-Menu |  | Smart | | | | |
|  | TV |  | Media | | | | |
|  | AV |  | AV | | | | |
|  | P<P |  | Pre Ch | | | | |
|  | PP |  | D. Menu | | | | |
|  | [≡] |  | Text | | | | |
|  | [≡o] |  | Subt | | | | |
|  | [≡+] |  | Format | | | | |
|  | [≡x] |  | 3D | | | | |
|  | [≡◆]/Wide |  | Shift + Format | | | | |
|  | [≡?] |  | Options | | | | |
|  | [≡i]/Guide |  | Guide | | | | |
|  | [::]/Subtitle |  | Back | | | | |
| | | | | | | | |
| | | | | | | | |





| Original | Replacement | Original | Replacement |
|--|---|---|--|
|  Power |  Power |  Stop |  Stop |
|  1 |  1 |  Play |  Play |
|  2 |  2 |  Pause |  Pause |
|  3 |  3 |  D-Menu |  Smart |
|  4 |  4 |  << |  << |
|  5 |  5 |  >> |  >> |
|  6 |  6 |  I<< |  I<< |
|  7 |  7 |  >>I |  >>I |
|  8 |  8 |  Time |  Shift + AV |
|  9 |  9 |  Zoom |  Shift + Eject |
|  0 |  0 |  Program |  Sleep |
|  -/--/+10 |  Guide |  Search Mode |  AV |
|  Exit |  Exit |  Repeat |  Text |
|  Red/↑/Return |  Red |  A-B |  Shift + Play |
|  Green/↓/Subtitle |  Green |  C |  Yellow |
|  Yellow/Audio |  Shift + Yellow |  Title |  Info |
|  Blue/Angle |  Blue |  Display |  Shift + Info |



