






































































































Original		Replacement		Original		Replacement	
	Power On		Power		Up		Up
	Power Off		Shift + Power		Down		Down
	Device On		Shift + Pre Ch		Right		Right
	Device Off		Shift + 0		Left		Left
	Quick Select		Red		Enter		Ok
	Quick Select 2 / (SAT/CBL)		Green		<</Band		<<
	Quick Select 3/(Dock)		Yellow		Play		Play
	CH+		Ch +		>>/Mode		>>
	CH-		Ch -		I<</Tuning		I<<
	Vol+		Vol +		Pause		Pause
	Vol-		Vol -		Stop		Stop
	Mute		Mute		>>I/Tuning Up		>>I
	Source Select		AV		MulteQ		Dual
	Menu		Menu		DYN EQ		Media
	CH Level/Top		Shift + Menu		DYN Vol		Subt
	Search/Setup		Options		Restorer		Exit
	Return		Back		Standard		Text





Original	Replacement
 D/ST	 Format
 Simulation	 3D
 Input Mode	 Info
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 +10/Memory	 Guide
 Shift/Link Menu	 Pre Ch
 V.Sel	 Rec
 Sleep	 Sleep

Original	Replacement
 Power Tv	 TV/R
 Input Tv	 Shift + AV
 Tv	 Shift + 1
 iPod	 Shift + 2
 DVD	 Shift + 3
 BD	 Shift + 4
 Tuner	 Shift + 5
 Dock	 Shift + 6
 SAT TU	 Shift + 7
 SAT/CBL	 Shift + 8
 Game	 Shift + 9
 V.AUX	 Shift + Guide

