





































Original	Replacement
 Power	 Power
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 FAV	 Fav / Marker / PC
 0	 0
 ALT	 Display / Media
 EPG	 Guide / EPG / -/--
 Info	 Info / Angle
 Menu	 Menu / Home

Original	Replacement
 Up	 Up
 CH+	 CH+ / Page+
 Exit	 Exit / Cancel / Clear
 Left	 Left
 OK	 OK
 Right	 Right
 Vol+	 Vol+
 CH-	 CH- / Page-
 Down	 Down
 List	 Smart / List
 Vol-	 Vol-
 Sub	 Subtitle / EQ
 Red	 Red / Netflix / Search
 Lang	 Shift + Audio / Lang I/II
 Blue	 Blue / Prime Video / Random
 Text	 Text / Goto
 Green	 Green / APP / Repeat





Original	Replacement	Original	Replacement
	Audio		Audio / Lang I/II
	Yellow		Yellow / YouTube / Repeat
	Pause		Pause / Step / Freeze
	Preview		Back / Return
	Tv/Radio		TV/Radio /
	Game		AV / Input / RDS
	Auto Scan		Zoom / Size

Original	Replacement

