









































































Original		Replacement		Original		Replacement	
	Power		Power		Down		Down
	1		1		Guia		Shift + Guide / EPG / -/-
	2		2		Piloto		Display / Media
	3		3		Serv		Fav / Marker / PC
	4		4		Red		Red / Netflix / Search
	5		5		Green		Green / APP / Repeat
	6		6		Yellow		Yellow / YouTube / Repeat
	7		7		Blue		Blue / Prime Video / Random
	8		8		E		Setup / OPT /
	9		9		Mute		Mute / Dimmer
	-/-/X/Prefe		Guide / EPG / -/-		+/Info		Info / Angle
	0		0		Perso		Text / Goto
	→/Salir/AV		Exit / Cancel / Clear		Tv/Sat		TV/Radio /
	Up		Up				
	Left		Left				
	OK/Select		OK				
	Right		Right				





Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 -/--/X/Prefe	 Guide / EPG / -/--
 0	 0
 ->/Salir/AV	 Exit / Cancel / Clear
 Vol+	 Vol+
 Up	 Up
 ZAP+	 CH+ / Page+
 Left	 Left

Original	Replacement
 Right	 Right
 Vol-	 Vol-
 Down	 Down
 ZAP-	 CH- / Page-
 Menu	 Menu / Home
 Guia	 Shift + Guide / EPG / -/--
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 E	 Setup / OPT /
 Mute	 Mute / Dimmer

