



Original	Replacement
	Power
	Subt
	Text
	TV/R
	Info
	Options
	Dual
	Format
	Exit
	Smart
	AV
	Pre Ch
	Ch +
	Ch -
	Up
	Down
	Right

Original	Replacement
	Left
	Vol +
	Vol -
	Menu
	Red
	Green
	Yellow
	Blue
	1
	2
	3
	4
	5
	6
	7
	8
	9



