



Original	Replacement	Original	Replacement
	Power		CH- / Page-
	Red / Netflix / Search		Right
	Mute / Dimmer		Left
	Green / APP / Repeat		Vol-
	Yellow / YouTube / Repeat		Menu / Home
	Blue / Prime Video / Random		OK
	Sleep / Timer		1
	Exit / Cancel / Clear		2
	Display / Media		3
	Back / Return		4
	Shift + TV/Radio / Program		5
	Audio / Lang I/II		6
	Text / Goto		7
	AV / Input / RDS		8
	Up		9
	CH+ / Page+		Guide / EPG / -/--
	Down		0



