























Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 FAV	 Pre Ch
 Menu	 Menu
 Recall	 Back
 Exit	 Exit
 TV/R	 TV/R

Original	Replacement
 Info	 Info
 CH+	 Ch +
 CH-	 Ch -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 EPG	 Guide
 Vol+	 Vol +
 Vol-	 Vol -
 Audio	 Dual
 Subtitle	 Subt
 Text	 Text
 Rec	 Rec
 Pause	 Pause
 <<	 <<





	Original		Replacement
	>>		>>
	Stop		Stop
	Rec List		List
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue

	Original		Replacement

