



Original	Replacement	Original	Replacement
	Power		Power
	EPG		Guide / EPG / -/--
	TXT		Text / Goto
	Source		AV / Input / RDS
	Q.Menu		D.Menu / Top
	*/O		Picture / Format
	*/Q		Setup / OPT /
	[+]		Zoom / Size
	i		Info / Angle
	Netflix		Shift + Red / Netflix /
	Exit		Exit / Cancel / Clear
	Multimedia		Display / Media
	Left		Left
	Up		Up
	Right		Right
	Internet		Smart / List
	OK		OK

Original	Replacement	Original	Replacement
	Menu		Menu / Home
	Down		Down
	Back		Back / Return
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Vol+		Vol+
	P+		CH+ / Page+
	Vol-		Vol-
	Mute		Mute / Dimmer
	P-		CH- / Page-
	1		1
	2		2
	3		3
	4		4
	5		5



