







































































| Original | Replacement | Original | Replacement |
|---|--------------|---|-----------------------|
|  | Mute |  | Mute / Dimmer |
|  | TV/Radio |  | TV/Radio / |
|  | Power |  | Power |
|  | NTSC/PAL |  | Picture / Format |
|  | Pause |  | Pause / Step / Freeze |
|  | Audio |  | Audio / Lang I/II |
|  | Last |  | Back / Return |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | i |  | Info / Angle |
|  | 0 |  | 0 |
|  | Sat |  | Shift + 0 |
|  | Sat |  | AV / Input / RDS |
|  | Menu |  | Menu / Home |
|  | Up / CH+ |  | Up |
|  | Up / CH+ |  | CH+ / Page+ |
|  | Exit |  | Exit / Cancel / Clear |
|  | Left / Vol- |  | Left |
|  | Left / Vol- |  | Vol- |
|  | OK |  | OK |
|  | Right / Vol+ |  | Vol+ |
|  | Right / Vol+ |  | Right |
|  | Down / CH- |  | Down |
|  | Down / CH- |  | CH- / Page- |
|  | Page- |  | Shift + CH- / |
|  | Page- |  | I<< / Preset- |
|  | Page+ |  | >>I / Preset+ |





| Original | Replacement | Original | Replacement |
|---|-------------|---|-----------------------------|
|  | Page+ |  | Shift + CH+ / |
|  | Fav |  | Fav / Marker / PC |
|  | Guide |  | Guide / EPG / -/- |
|  | Red / F1 |  | Red / Netflix / Search |
|  | Green / F2 |  | Green / APP / Repeat |
|  | Yellow / F3 |  | Yellow / YouTube / Repeat |
|  | Blue / F4 |  | Blue / Prime Video / Random |
|  | Text |  | Text / Goto |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Replacement | Original | Replacement |
|----------|-------------|----------|-------------|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

