







































































Original		Replacement		Original		Replacement	
	Power		Power		Info		Info
	Input		AV		Vol+		Vol +
	P.Mode		Shift + Format		Vol-		Vol -
	P.Size		Format		Mute		Mute
	S.Mode		Shift + Dual		CH.List		List
	Sleep		Sleep		Home		Smart
	1		1		CH+		Ch +
	2		2		CH-		Ch -
	3		3		*		Menu
	4		4		[≡]		Options
	5		5		Back		Back
	6		6		Exit		Exit
	7		7		Up		Up
	8		8		Down		Down
	9		9		Right		Right
	0		0		Left		Left
	Guide		Guide		OK		Ok





Original		Replacement		Original		Replacement	
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	<<		<<				
	Play		Play				
	>>		>>				
	Stop		Stop				
	Pause		Pause				
	Rec		Rec				
	Subtitle		Subt				
	Language		Dual				
	TXT		Text				
	DMP		3D				
	You Tube		Media				
	Netflix		Shift + Smart				
	Wuaki.Tv		TV/R				

