











































| Original | | Replacement | | Original | | Replacement | |
|---|--------------|---|--------|---|--------|---|--------|
|  | Standby / On |  | Power |  | Size |  | Eject |
|  | Vol+ |  | Vol + |  | P.Mode |  | Format |
|  | Vol- |  | Vol - |  | Return |  | Back |
|  | RGB |  | 1 | | | | |
|  | HDMI |  | 2 | | | | |
|  | Mute |  | Mute | | | | |
|  | Standby |  | Ch - | | | | |
|  | On |  | Ch + | | | | |
|  | Menu |  | Menu | | | | |
|  | Up |  | Up | | | | |
|  | Left |  | Left | | | | |
|  | OK |  | Ok | | | | |
|  | Right |  | Right | | | | |
|  | Down |  | Down | | | | |
|  | Recall |  | Pre Ch | | | | |
|  | Input |  | AV | | | | |
|  | Auto |  | Media | | | | |

