





Original	Replacement
Power	Power
Mute	Mute
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
---/	Guide
Preview	Pre Ch
Sound	Dual
Picture	Shift + Format
Aspect	Format

Original	Replacement
Still	Pause
S.Mode	Shift + Dual
Sleep	Sleep
Volume+	Vol +
Volume-	Vol -
Channel+	Ch +
Channel-	Ch -
PIP On/Off	Smart
Source	Shift + AV
Size	Eject
Swap	Back
Up / P-CH +	Up
Down / P-CH -	Down
Right	Right
Left	Left
Menu	Menu
Menu	Ok





Original	Replacement
 Exit	 Exit
 TV / AV	 AV
 Info	 Info
 Wiper	 Media
 PC Auto	 Options
 TTX On/Off	 Text
 TTX / Mix	 Shift + Text
 Index	 Shift + Info
 List / FLOF	 Shift + Smart
 Store	 TV/R
 Hold	 Stop
 Reveal	 Shift + Subt
 Subpage	 Subt
 Size	 Shift + Eject
 Red	 Red
 Green	 Green
 Yellow	 Yellow

Original	Replacement
 Blue	 Blue

