




















































































































Original	Replacement	Original	Replacement
 Power	 Power	 Recall	 Pre Ch
 TV/SAT	 AV	 Exit	 Exit
 Mute	 Mute	 OK	 Ok
 1	 1	 Up	 Up
 2	 2	 Down	 Down
 3	 3	 Right	 Right
 4	 4	 Left	 Left
 5	 5	 Vol+	 Vol +
 6	 6	 Vol-	 Vol -
 7	 7	 CH/Page+	 Ch +
 8	 8	 CH/Page-	 Ch -
 9	 9	 Red	 Red
 0	 0	 TTX	 Text
 SAT	 Smart	 Green	 Green
 FAV	 Shift + Pre Ch	 SUB. T	 Subt
 Menu	 Menu	 SUB. T	 Subt
 EPG	 Guide	 Yellow	 Yellow
		 Zoom	 Eject

Original	Replacement	Original	Replacement
 Recall	 Pre Ch	 TV	 AUX
 Exit	 Exit	 DVD	 SAT
 OK	 Ok	 MUTE	 SHIFT
 Up	 Up	 PLAY MODE	 REC MODE
 Down	 Down	 PAUSE	 STOP
 Right	 Right	 LEFT	 RIGHT
 Left	 Left	 DISC NAV	 SOUND
 Vol+	 Vol +	 AD	 SETTINGS
 Vol-	 Vol -	 LIST	 DUAL
 CH/Page+	 Ch +	 SUBT	 OPT
 CH/Page-	 Ch -	 PROG	 SEARCH
 Red	 Red	 PICTURE	 ECO
 TTX	 Text	 SLEEP	 TV/R
 Green	 Green	 FORMAT	 3D
 SUB. T	 Subt	 E-MANUAL	 REPEAT
 SUB. T	 Subt	 ZOOM	 TIMER
 Yellow	 Yellow	 D.MENU	 TEXT
 Zoom	 Eject	 TOP MENU	 DISPLAY
		 MENU	 INFO
		 OK	 RETURN
		 EXIT	 BACK
		 VOL+	 HOME
		 VOL-	 SMART
		 CH+	 APP
		 CH-	 MEDIA
		 Red	 CH+
		 TTX	 CH-
		 Green	 1
		 SUB. T	 2
		 SUB. T	 3
		 Yellow	 4
		 Zoom	 5
			 6
			 7
			 8
			 9
			 0
			 FAV
			 GUIDE
			 PRE-CH
			 A
			 B
			 C
			 D
			
			





Original		Replacement		Original	Replacement
	Blue		Blue		
	MP		3D		
	Tv/Radio		TV/R		
	Audio		Dual		
	Pause		Pause		
	Rec		Rec		
	Info		Info		
	P/N	 + 	Shift + Media		
	POS		Media		
	T/S		Options		
	<<		<<		
	>>		>>		
	Play		Play		
	Stop		Stop		

