






































Original	Replacement
 Power	 Power
 Tv/R	 TV/R
 TTX	 Text
 Sub.T	 Subt
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Back	 Back
 SAT	 Smart

Original	Replacement
 Find	 Media
 M/P	 D. Menu
 Tv/AV	 AV
 Exit	 Exit
 Menu	 Menu
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Back	 Back
 SAT	 Smart



