





































| Original  | Replacement  | Original  | Replacement    |
|---|--|---|----------------|
|  Power |  Power        |  16:9              | 16:9           |
|  Sleep |  Sleep        |  Lang              | Lang           |
|  Mute  |  Mute         |  RCL               | RCL            |
|  Timer |  AV           |  FAV               | FAV            |
|  EPI   |  Guide        |  Page+ / Timeshift | Shift + Ch +   |
|  SUBTL |  Subt         |  Page- / V-Format  | Shift + Ch -   |
|  Audio |  Shift + Dual |  Page- / V-Format  | Shift + Format |
|  1     |  1            |  Up / CH+          | Up             |
|  2     |  2            |  Up / CH+          | Ch +           |
|  3     |  3            |  Down / CH-        | Down           |
|  4     |  4            |  Down / CH-        | Ch -           |
|  5    |  5           |  Right / Vol+     | Right          |
|  6   |  6          |  Right / Vol+    | Vol +          |
|  7   |  7          |  Left / Vol-     | Left           |
|  8   |  8          |  Left / Vol-     | Vol -          |
|  9   |  9          |  OK              | Ok             |
|  0   |  0          |  Menu            | Menu           |

| Original   | Replacement    | Original  | Replacement |
|--|----------------|---|-------------|
|  Format         | Format         |  TV        | DVD         |
|  Dual           | Dual           |  SAT       | AUX         |
|  Back           | Back           |  PLAY MODE | REC MODE    |
|  Pre Ch         | Pre Ch         |  DISC NAV  | SOUND       |
|  Shift + Ch +   | Shift + Ch +   |  SOUND     | AD          |
|  Shift + Ch -   | Shift + Ch -   |  SETTINGS  | OPT         |
|  Shift + Format | Shift + Format |  LIST      | DUAL        |
|  Up             | Up             |  PROG      | SEARCH      |
|  Ch +           | Ch +           |  PICTURE   | ECO         |
|  Down           | Down           |  SLEEP     | TV/R        |
|  Ch -           | Ch -           |  FORMAT    | 3D          |
|  Right         | Right          |  E-MANUAL  | REPEAT      |
|  Vol +        | Vol +          |  ZOOM      | TIMER       |
|  Left         | Left           |  D.MENU    | TEXT        |
|  Vol -        | Vol -          |  TOP MENU  | INFO        |
|  Ok           | Ok             |  OK        | RETURN      |
|  Menu         | Menu           |  EXIT      | BACK        |



