







































































Original		Replacement		Original		Replacement	
	Power		Power		Exit / Settings		Exit
	Mute		Mute		YouTube		Media
	1		1		Vol+		Vol +
	2		2		Vol-		Vol -
	3		3		Info		Info
	4		4		EPG		Guide
	5		5		PR+		Ch +
	6		6		PR-		Ch -
	7		7		Up		Up
	8		8		Left		Left
	9		9		OK		Ok
	0		0		Right		Right
	CH List		List		Down		Down
	Return / Back		Back		Rec		Rec
	Menu		Menu		Nicam / I/II		Dual
	Source		AV		Text		Text
	Home		Smart		AD / Sub-Page		Subt





Original		Replacement		Original	Replacement
	FAV / Size		Pre Ch		
	Quick / Hold / Freeze	 + 	Shift + Stop		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
	Play/Pause / Index		Play		
	Play/Pause / Index		Pause		
	<< / Reveal		<<		
	>> / Mix		>>		
	Stop / Cancel		Stop		

