






























































































Original	Replacement	Original	Replacement
	Standby		Power
	Auto		Smart
	Tv/Radio		TV/R
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Shift + Guide
	Back		Back
	Vol+		Vol +
	Vol-		Vol -
	CH+		Ch +
	CH-		Ch -
	Nicam/A2		Options
	Aspect		3D
	Display		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Menu		Menu
	Exit		Exit
	Source		AV
	P.Mode		Shift + Format
	S.Mode		Shift + Dual
	Sleep		Sleep





Original		Replacement		Original		Replacement	
	Fav		Pre Ch		Rec		Rec
	Fav-		Shift + Ch -		Stop		Stop
	Fav+		Shift + Ch +		I<<		I<<
	Hold		Shift + AV		>>I		>>I
	EPG		Guide		Red		Red
	Text		Text		Green		Green
	Lang		Dual		Yellow		Yellow
	Subtitle		Subt		Blue		Blue
	Index		List				
	Reveal		Eject				
	Subpage		D. Menu				
	Media		Media				
	Size		Format				
	Play		Play				
	Pause		Pause				
	<<		<<				
	>>		>>				

