










































	Original	Replacement		Original	Replacement
	Mute		Mute		3 Stereo
	Volume+		Vol +		Stereo
	Volume-		Vol -		0dB
	Test		Text		Input AUX
	Surround+		Ch +		Input Video
	Surround-		Ch -		
	Center+		Up		
	Center-		Down		
	Balance L		Left		
	Balance R		Right		
	Treble-		<<		
	Treble+		>>		
	Bass-		I<<		
	Bass+		>>I		
	Pro Logic		1		
	Phantom		2		
	Simulated		3		

