







Original	Replacement
	Power
	Mute
	P.Mode
	S.Mode
	FAV
	Sleep
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Shift + Guide / EPG / -/--
	0

Original	Replacement
	Back
	Vol+
	CH List
	CH+ / Page+
	Vol-
	Aspect
	CH- / Page-
	EPG
	Audio
	Rec
	Menu
	Up
	Exit
	Left
	Enter
	Right
	Source





Original	Replacement
Down	Down
Display	Display / Media
Red	Red / Netflix / Search
<<	<< / Tune-
Green	Green / APP / Repeat
>>	>> / Tune+
Yellow	Yellow / YouTube / Repeat
I<<	I<< / Preset-
Blue	Blue / Prime Video / Random
>>I	>>I / Preset+
Text	Text / Goto
Stop	Stop / Hold
Play	Play / Slow
Pause	Pause / Step / Freeze
Index	Info / Angle
Size	Zoom / Size
Reveal	D.Menu / Top

Original	Replacement
Hold	Shift + Stop /
Subpage	Eject / Surround
Subtitle	Subtitle / EQ

