





























































Original	Replacement	Original	Replacement
 Open/Close	 Eject / Surround	 7	 7
 Standby Tv	 Shift + Power	 9 Tv	 Shift + 9
 Standby	 Power	 8	 8
 1 Tv	 Shift + 1	 9	 9
 2 Tv	 Shift + 2	 0 Tv	 Shift + 0
 2	 2	 0	 0
 3 Tv	 Shift + 3	 -/-- Tv	 Guide / EPG / -/--
 1	 1	 10	 Shift + Guide / EPG / -/--
 4 Tv	 Shift + 4	 +10	 Fav / Marker / PC
 3	 3	 Return	 Back / Return
 4	 4	 Page	 Setup / OPT /
 5 Tv	 Shift + 5	 Title/Group	 Info / Angle
 5	 5	 Tv/Video	 Shift + TV/Radio / Program
 6 Tv	 Shift + 6	 Cancel	 Exit / Cancel / Clear
 7 Tv	 Shift + 7	 Top Menu	 D.Menu / Top
 6	 6	 Choice	 TV/Radio /
 8 Tv	 Shift + 8	 Menu	 Menu / Home





Original	Replacement
CH+ Tv	Shift + CH+ /
Up	Up
CH- Tv	Shift + CH- /
Vol- Tv	Shift + Vol-
Down	Down
Vol+ Tv	Shift + Vol+
Right	Right
Enter	OK
Left	Left
I<</Previous	I<< / Preset-
On Screen	Display / Media
>>I/Next	>>I / Preset+
Stop/Clear	Stop / Hold
Play/Select	Play / Slow
Pause/Strobe	Pause / Step / Freeze
<</Slow-	<< / Tune-
>>/Slow+	>> / Tune+

Original	Replacement
Repeat	Green / APP / Repeat
Subtitle	Subtitle / EQ
Audio/fs/Rate	Audio / Lang I/II
VFP/Progressive Scan	Picture / Format
Digest	AV / Input / RDS
Angle	Shift + Info / Angle
Zoom-	CH- / Page-
Zoom+	CH+ / Page+
3D Phonic	Zoom / Size
PAL/NTSC	Sleep / Timer
Amp Vol-	Vol-
Amp Vol+	Vol+
Muting Tv	Mute / Dimmer

