
































































Original	Replacement	Original	Replacement
 Standby	 Power	 Up / CH+	 Ch +
 Mute	 Mute	 Down / CH-	 Down
 1	 1	 Down / CH-	 Ch -
 2	 2	 Right / Vol+	 Right
 3	 3	 Right / Vol+	 Vol +
 4	 4	 Left / Vol-	 Vol -
 5	 5	 Left / Vol-	 Left
 6	 6	 OK	 Ok
 7	 7	 Menu	 Menu
 8	 8	 Exit	 Exit
 9	 9	 Text	 Text
 0	 0	 List	 List
 Recall	 Back	 Audio	 Dual
 Pause	 Pause	 Subtitle	 Subt
 Guide	 Guide	 P/N / Search	 Shift + TV/R
 Info	 Info	 TV / Radio	 TV/R
 Up / CH+	 Up	 DTV/VCR / Mode	 AV



