










































Original	Replacement	Original	Replacement
 Standby	 Power	 Book.J	 Shift + 3D
 Mute	 Mute	 R.Skip	 I<<
 1	 1	 REW	 <<
 2	 2	 FWD	 >>
 3	 3	 F.Skip	 >>I
 4	 4	 Rec	 Rec
 5	 5	 Stop	 Stop
 6	 6	 Play	 Play
 7	 7	 Pause	 Pause
 8	 8	 Menu	 Menu
 9	 9	 Exit	 Exit
 0	 0	 Info	 Info
 F.List	 Media	 Back	 Back
 RES	 Smart	 Up	 Up
 Repeat	 Text	 Left	 Left
 Capture	 Format	 OK	 Ok
 Book.M	 3D	 Right	 Right





Original	Replacement	Original	Replacement
 Down	 Down	 Option1	 Options
 Volume+	 Vol +	 Option2	 Shift + Options
 Volume-	 Vol -	 TV / Radio	 TV/R
 CH/Page+	 Ch +	 TV / STB	 AV
 CH/Page-	 Ch -		
 Red / Audio	 Red		
 Red / Audio	 Dual		
 Green / Subt	 Green		
 Green / Subt	 Subt		
 Yellow / Text	 Yellow		
 Yellow / Text	 Shift + Text		
 Blue / Sleep	 Blue		
 Blue / Sleep	 Sleep		
 EPG	 Guide		
 FAV	 Pre Ch		
 SAT List	 List		
 Zoom	 Eject		

