







































































Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Q.View	 Sound / Title
 Home	 Menu / Home
 Q.Menu	 D.Menu / Top
 Guide	 Guide / EPG / -/--
 List	 Smart / List
 Mute	 Mute / Dimmer

Original	Replacement
 Input	 AV / Input / RDS
 Tv/Rad	 TV/Radio /
 AV Mode	 Shift + AV / Input / RDS
 Energy/Saving	 Eject / Surround
 Portal	 Display / Media
 Vol+	 Vol+
 Vol-	 Vol-
 P+	 CH+ / Page+
 P-	 CH- / Page-
 Info	 Info / Angle
 Exit	 Exit / Cancel / Clear
 Back	 Back / Return
 OK	 OK
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left





Original	Replacement	Original	Replacement
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Text		Text / Goto
	Subtitle		Subtitle / EQ
	AD		Audio / Lang I/II
	Play		Play / Slow
	T.Opt		Setup / OPT /
	Alarm		Sleep / Timer
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze
	Simplink		Zoom / Size
	<<		<< / Tune-
	>>		>> / Tune+
	Ratio		Picture / Format
	Mark		Fav / Marker / PC

