


































































Original	Replacement
 Power	 Power
 Tv/Radio	 TV/R
 Cable	 AV
 Ajustes	 Menu
 Live Zoom	 Format
 Subtitle	 Subt
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 List	 List

Original	Replacement
 Guide	 Guide
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Info	 Info
 Search	 Shift + TV/R
 P+	 Ch +
 P-	 Ch -
 Recent	 Media
 Live Menu	 D. Menu
 Back	 Back
 Home	 Smart
 Exit	 Exit
 Text	 Text
 T.Opt	 Options
 Up	 Up
 Down	 Down





Original	Replacement	Original	Replacement
 Right	 Right		
 Left	 Left		
 OK	 Ok		
 AD	 +  Shift + Subt		
 Rec/*	 Rec		
 Stop/Line Tv	 Stop		
 <<	 <<		
 Play	 Play		
 Pause	 Pause		
 >>	 >>		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

