











































































Original	Replacement	Original	Replacement
 Power	 Power	 Q.View	 D. Menu
 Tv/Rad	 TV/R	 FAV/Quick	 Pre Ch
 Search	 Shift + TV/R	 Info	 Info
 Live Zoom	 Eject	 Vol+	 Vol +
 *	 Menu	 Vol-	 Vol -
 Source	 AV	 Mute	 Mute
 1	 1	 P+	 Ch +
 2	 2	 P-	 Ch -
 3	 3	 Netflix	 Shift + Media
 4	 4	 Home	 Smart
 5	 5	 Amazon	 Media
 6	 6	 Text	 Text
 7	 7	 Back	 Back
 8	 8	 T.Opt/Magic Link	 Options
 9	 9	 Exit	 Exit
 0	 0	 Up	 Up
 Guide	 Guide	 Down	 Down





Original	Replacement	Original	Replacement
	Right		Right
	Left		Left
	OK		Ok
	AD/*		Subt
	Rec		Rec
	Stop		Stop
	<<		<<
	Play		Play
	Pause		Pause
	>>		>>
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue

